Linear Response Time-Dependent Density Functional Theory



Ankit Mishra

Hiroyuki Kumazoe, Aravind Krishnamoorthy

Collaboratory for Advanced Computing and Simulation
Department of Material Science & Department of Physics
University of Southern California







Problem Statement



- Compute the optical absorption spectrum of a 2×2 unit cell of α Tellurene based on Linear response time dependent density functional theory.
- Objective is to perform the above the task with and without long-range exactexchange correction.

Absorption spectrum,
$$\alpha(\omega) = \sum_{I} \frac{f_I}{\omega - \omega_I}$$
,

 ω_I is the I-th excitation energy, with $|I\rangle$ is the I-th excited-state wave function with $|O\rangle$ being the ground state





Outline of the solution



- Obtain the ground state information corresponding to α *Tellurence*.
- Use the ground state information to estimate the excited behavior using time dependent density functional theory without long-range exact-exchange correction.
- Similarly estimate the excited behavior employing linear response to TD-DFT with the long-range exact-exchange correction.









```
*start(on/off)
(how of it)
  .false.
                                            (lstart)
*end
*linear-response TDFT
(how of it)
                                          : (lrtddft)
.false.
(whether to specify states)
.true.
(long-range exchange scheme) :
   .false.
                                          : (llcexchange) long-range correction for exchange
*molecular dynamics
(how of it)
                                          : (ifmd) = 0:non, 1:CG, 2:NVE-MD, 3:NVT-MD
(time step)
 0.1d0 50
                                          : (dtmd, nstop) time step, total step (dtmd = 120.d0)
```





Hands-on: Examine Input File



QXMD

```
*start(on/off)
```

(how of it)

.false. : (lstart)

*end

*linear-response TDFT

(how of it)

.false. : (lrtddft)

(long-range exchange scheme)

.false. : (llcexchange) long-range correction for exchange

- **lstart** determines if the simulation runs from t=0 or subsequent steps.
- Irtddft determines calculation of the Casida coupling matrix.
- **llexchange** determines whether or not we want to incorporate long range correction for exchange functional.



Hands-on: Examine Input File



*molecular dynamics : (how of it) :

(ifmd) = 0:non, 1:CG, 2:NVE-MD, 3:NVT-MD

(time step)

0.1d0 50 : (dtmd, nstop) time step, total step (dtmd = 120.d0)

time step: Time step in [a.u.] for numerically integrating TDDFT equations

how of it: 0 to run non adiabatic MD for 50 time steps at 300K





Zero point energy calculation



Check your current directory

Is /yourWorkSpace/QXMD-Repo/examples/06-LRTDDFT/Te

Ensure you have the following in the directory

O.lrtddft=F 1.lrtddft=T 6.llcexchange=T

- Go to 0.lrtddft=F to submit the zero point energy calculation which will be used subsequently to estimate the excited state information and compute the absorption spectrum.
- Before submitting, please ensure the following in your control folder ls *O.lrtddft=F/control*

Opt.Te12-beta_GGA.ion PAW filename input.config input.file





TDDFT calculation without long-range exactexchange correction



- After estimating the ground state energies and information proceed to next step.
- Go to 1.lrtddft=T folder in /yourWorkSpace/QXMD-Repo/examples/06-LRTDDFT/Te
- Ensure you have following in your control folder

 Opt.Te12-alpha_GGA.ion Opt.Te12-beta_GGA.ion PAW filename input.config input.file
- Ensure you have lstart and lrtddft flags turned on. Here, llexchange will be turned off
- Also, make sure you have band index of hole as 31 and band index of particle as 38.
- Copy the contents of O.Irtddft=F/data to 2.Irtddft=T/data
- Submit the job





TDDFT calculation without long-range exactexchange correction



- After estimating the ground state energies and information proceed to next step.
- Go to 6.llexchange=T folder in /yourWorkSpace/QXMD-Repo/examples/06-LRTDDFT/Te
- Ensure you have following in your control folder Opt.Te12-beta_GGA.ion PAW filename input.config input.file
- Ensure you have lstart, lrtddft, llexchange flags turned on.
- Also, make sure you have band index of hole as 31 and band index of particle as 38.
- Copy the contents of O.Irtddft=F/data to 6.Ilexchange=T/data
- Submit the job





Analysis of absorption spectrum



- Corresponding to to 1.lrtddft=T and 6.llexchange=T check for Oscillator strength folder.
- Edit the *oscillator_strength.f90* file to locate the relative position of your corresponding *data* folder.
- If everything went fine, you should see an output file Oscillator_strength.dat.
- The content of this file should look similar to following output.

```
# Optical absorption spectra represented as oscillator strengths
# Gaussian filter = 0.050000 [eV]
# E (eV) f_x f_y f_z ave
0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
1.00000E-02 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
2.00000E-02 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
3.00000E-02 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
4.000000E-02 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
5.000000E-02 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
6.000000E-02 0.000000E+00 0.000000E+00 0.000000E+00 0.000000E+00
```





Analysis of absorption spectrum (contd.)



• Once you have obtained *Oscillator_strength.dat*. with and without exact exchange correction, plot the average corresponding to 5th column w.r.t energies in the first column.





